



Fiberglass Gutter Installation Instructions



SAND ALL BONDING AREAS WITH 36 GRIT SANDPAPER (INCLUDED WITH GUTTERGLUE KIT) PRIOR TO APPLYING GUTTERGLUE!

Fiberglass Building Products Inc. accepts no liability or responsibility for the improper installation of this product.

Visit:

<https://fiberglass.com/installation/>

**For Complete Installation
Instructions**

Tools Required to complete FiberGutter Installation

Proper Staging (OSHA Approved), Cordless Impact Driver with bit extender, Chop Saw with Diamond Blade, 6' level, Chalk Line, Tape Measure, Latex/Nitrile Gloves, Utility Knife (for trimming excess fiberglass on miters/seams), 2-3/8" Hole Saw (Outlet), Safety Glasses, Rags & Acetone.

Painting FiberGutter

Fiberglass is generally painted with the trim boards after installation. In general paint will stick to fiberglass 5 times longer than wood.

Surface Preparation

Use 80 Grit sandpaper over the entire surface of the gutter that is going to be painted. For best adhesion it is recommended to just sand until the gloss is no longer visible.

Wipe clean with acetone before and after sanding for best results.

Paint Application

We have found that pretty much any exterior acrylic latex paint/primer combo works very well. 2 Coats is recommended. We insist that you follow the recommendations of the paint manufacturer.



Fiberglass Building Products Inc. 546 Plymouth St Halifax, MA 02338

Technical Support: (781) 754-0118

www.fiberglass.com